

QUICK APPLICATION TIPS

When wrapping hard surfaces like melamine kitchen cupboards and doors, we recommend using a solvent based adhesion promoter for the edges and a water-based primer for the large surfaces, like raw Supawood or Rhinolite.

It is advisable to perform an adhesion test first. Test kits are available from Maizey Plastics. (Acceptable adhesion is 300gr per square inch for your test strip)

Give flat surfaces a light sand and then fill any scratches, gouges or holes. This can be done with any wood filler or automotive body filler. If there is no edging and the chipboard is damaged, body filler works very well.

The surface would then need to be wiped down with an ISO Propyl alcohol mix (70% ISO & 30% water) and primed before starting with application of the film.

When preparing plastered walls, a solvent based primer should be used, NOT a water-based primer. The same goes for dry walling.

It is still advisable to do an adhesion test first and then apply the recommended adhesion promoters on top of this.



COVER STYL' DISTRIBUTION PARTNER

RECOMMENDED PRIMERS

- For hard surfaces : 3M Primer 94
- For porous surfaces like Rhinolite, Supawood, walls etc: Maizey Wall Primer

RECOMMENDED SUBSTRATES	SUBSTRATE TYPES NOT RECOMMENDED
Plaster Board	Brick Walls
Melamine	Raw Fibreglass
Formica	Existing Wallpaper
Rhinolite	Damaged Chipboard
Painted Walls	Vehicles
Glass	Fabrics
Metals	Wet Paint
Plastics	Cracked Walls
Raw Wood	Rough Tiles
Ceiling Board	Damp Areas
Aluminium	Damaged Tiles
Granite	Rough Plaster
Smooth Concrete	Rust
	Textured Paints

WARRANTY INFORMATION

Coverstyl offers a 10-YEAR product warranty against delamination, cracking fading or other changes in appearance.

A 3 -5 year installation warranty will only be issued to a certified Cover Styl' Partner dependant on the surface it has been applied to.

(Contact us for details on training and certification.)